



R'N'PLAY

SECURITY INFORMATION

This appliance was designed and manufactured to ensure your safety. The security mechanisms incorporated in the product will protect you if you observe the following procedures for installation, use and troubleshooting: read carefully the following instructions and observe them before handling and installing your hardware. Save these instructions so that you can refer to later.

Some people are susceptible to seizures or have loss of consciousness at the sight of certain kinds of flashing lights or frequent elements in our environment. Those people are exposed to attacks when they watch certain images or playing certain video games.

These phenomena may occur even though the subject has no established medical history or has never been confronted with an epileptic seizure. If you have already submitted symptoms related to epilepsy (seizures or loss of consciousness) in the presence of light stimulations, consult your doctor.

GENERALITIES

Do not shake the product under penalty of damaging it.

Use only parts and accessories (power supply...) specified by the manufacturer.

The illustrations of the product may vary from the actual product.

SECURITY

To avoid fire or electric shock, do not place the appliance near objects filled with liquid.

If a heavy object or liquid should fall on the device, have it checked by qualified personnel before using it again.

In operation, the surface of the housing gives off heat; therefore, do not cover it or put an object on it.

POWER SUPPLY

The supplied power adapter is specific to the product. The use of a different adapter may damage the product or cause accidents.

PRODUCT LOCATION

Install the unit away from any equipment to strong attraction such as microwave, large speakers...

LEANING

Never open the product to clean otherwise will void the warranty. Unplug the product from the wall outlet before cleaning the product. Clean the outside of the product with a soft, dry cloth. Never use abrasive cloth, scouring powder or solvent such as alcohol or gasoline.

TROUBLESHOOTING

Refer all servicing to qualified personnel. Troubleshooting is necessary if the appliance has been damaged in any way: plug or power cord damaged, liquid spilled on the product, introduction of small objects in the product, exposure to rain or moisture, malfunctions, dropping the product...

IMPORTANT HINT

At full volume, listening to the player for an extended period of time can damage your hearing.

It is illegal to download music from Internet without buying the rights to do so. STOREX is not responsible for the use of illegally downloaded music.

SECURITY - ENVIRONMENT

Your STOREX product has been tested in the laboratory; It is complies with the European directives for CE marking in force at the time of its marketing.

Traceability of the components of your STOREX product has carried out; she showed us the conformity of the product with environmental directive (ROHS) in force at the time of its marketing.

At the end of life, do not dispose in the garbage but bring to your site who will move the product in a chain of electrical, electromechanical and electronic waste (WEEE) recycling.

Children: Be very careful with the children.

This product contains many spare parts, therefore to be very alert when a child is in contact with. The product contains small parts that can be ingested or cause choking if swallowed. Your device is equipped with a camera or a lighting device, do not use it too close to the eyes of children or animals.

Audition: At full power, listening to extended periods can damage your hearing. Be sure to reduce the volume to the minimum necessary when you listen to music or a conversation. Avoid high sound volumes for long periods.


PARTS AND CONTROL

TOP



- 1. F1/F2 : Quick Play.
- 2. Urn On or turn Off the speaker.
- 3. WPS : Set a new connection/ Play or Pause.
- 4. VOL+ : Raise the volume.
- 5. VOL- : Low the volume.

REAR




- 1. AUX IN : To connect an audio device.
- 2. DC IN : To connect the power supply.
- 3. LAN : To ceonnect the speaker to the network.
- 4. USB : To connect an USB device.

CONNECT R'N'PLAY TO THE NETWORK

- 1. Connect the power supply to the speaker.
- Download the application « R'n'Play » on Play Store or l'AppStore, then launch it on your smartphone.
- Click on « Add Device » then click on WPS key on the speaker.



 Click « NEXT » on upper right corner on the screen then input the WiFi keypass of your router.




5. You have connected you speaker to your network.


MULTI-ROOM MODE

Several speakers can be paired in order to listen to music in multiple rooms at the same time.

1. in the list of devices, stay press on the speaker, and then slide the new device (speaker) up in order to pair it.




2. To return to the '**solo**' mode, proceed as above, but slide the device down to disconnect it from the other speaker.




PLAY MUSIC FROM YOUR SMARTPHONE

- 1. Select 'My Music' on the side panel of the application.
- **2.** Select your phone from the list, and then select the folder where your audio files are located.



PLAY MUSIC FROM INTERNET AUDIO SERVICES

1. Select an audio internet platform on the side panel of the application.



GUARANTEE CONDITIONS

STOREX's available guarantee is valid for 2 year for your product and 3 months for its accessories (power supply, USB cables...).

STOREX guarantees your products against any manufacturing or assembling faults. This guarantee only applies to the first purchase of your product by the end user and is not transferable if the device is resold. This warranty does not cover any incompatibilities found by end user apart from recommendations specified on the packaging, or any other incompatibility generated by other hardware or software on the computer that is connected to the your product.

Proof of purchase must be presented to our services to apply **STOREX** guarantee.

The guarantee doesn't cover failures or defects induced by non-compliance to this manual's instructions, neglect, alteration, improper installation or maintenance, reparation or alteration not authorized by **STOREX**, improper tests, accident or external factor such as (not exhaustive) excessive heat or dampness, power failures or bad installation / uninstalling of your product. The only contractual obligation endorsed by **STOREX** pertains to the reparation or replacement of a defective product. In no case, **STOREX** cannot be held responsible for any loss of data, or its consequences induced by operational fault or a product failure. In any case, **STOREX** won't be bound to any financial responsibility for any amount exceeding the value of the product purchased by the end user.

This guarantee is well defined and cannot be modified, decreased or increased without written consent from **STOREX**. In addition, **STOREX** cannot be held responsible for any technical advice or service provided in relation to your product.

For any request not covered by this guarantee, please contact **STOREX** support or log on to <u>www.e-storex.com</u> to order accessories.

You are not the grantee of this current warranty. This warranty covers only your product and is governed by French law. You

STOREX WEBSITE

Please visit our website: <u>http://www.storex.fr</u>.

Select "**Accessories**" category. You can download the latest full version of the manual as well as software updates.

GUARANTEE REGISTRATION

To facilitate your support during any call with our support team, we invite you to register the warranty of your product on our Web site at the address: <u>http://garantie.storex.eu</u>

In case of failure, please contact STOREX support to repair your product under warranty, or please send your request by e-mail to the address:

support@storex.eu

or by phone at

France:	01 55 85 82 00 (<u>support.fr@storex.eu</u>)
Portugal:	308 800 836 (apoio.pt@storex.eu)
Spain:	902 110 572 (<u>soporte.es@storex.eu</u>)
England:	(<u>support.uk@storex.eu</u>)
From Monday to Thursday - 09h30 at 19h30.	

Friday - 9h30 at 18h30.

