

CUHD4K-DUAL




Content

WORKING MODE FLOW CHART	6
USE YOUR CAMERA.....	8
APPLICATION (SUPPORT ANDROID AND IOS).....	17
WATERPROOF CASE	22
SECURITY INFORMATION	23
GENERAL.....	23
SAFETY.....	24
PRODUCT'S POWER SUPPLY	24
PLACING OF THE PRODUCT	25

CLEANING	25
TROUBLESHOOTING	26
IMPORTANT NOTE	26
SAFETY-ENVIRONMENT	27
GUARANTEE CONDITIONS	28
STOREX WEBSITE	31
WARRANTY REGISTRATION	31

WORKING MODE FLOW CHART

After turn on the camera, you can press the **Power/Mode** button to switch the following modes in turn:




	Video	Record Video
	Photo	Capture a single photo.
	Burst Photo	Capture photo bursts
	Time Lapse	Shoot a series of photos at set time intervals
	Settings	Adjust camera settings, resolution and more.

USE YOUR CAMERA

When you use the camera for the first time, please:

1. Insert a micro SD or micro SDHC card, as shown in the following picture.



High speed card at least Class 4 is recommended; when using time delay function or recording video in professional mode, the card of Class 10 is required.

Turn off the camera before inserting or removing the card.

Charging the battery

The camera uses removable rechargeable lithium battery. When the camera is off, connect it to the PC via USB cable to charge the battery. **During charging, the status indicator (blue) will light on, and the indicator off when charging completes.**

Note: When the camera is on, connecting it to the PC will not charge.

Turn on/off

Turn on: press and hold the  button for about 3 seconds, LCD displays “**ON**” and a beep can be heard from buzzer.

Turn off: press and hold the  button for about 3 seconds, LCD displays “**OFF**” and a beep can be heard from buzzer.

Note: The camera will turn off automatically if it is idle for 5 minutes.

Start to Use



To record Video, verify the camera is in Video mode. If the Video icon on your camera's LCD screen is not showing, press the Power/Mode Button repeatedly until it appears.

To start recording:

Press the Shutter/Select Button. The camera will emit one beep and the Camera Status Lights will flash while recording.

To stop recording:

Press the Shutter/Select Button. The Camera Status Lights stop flashing and the camera emits one beep to indicate recording has stopped.

This camera automatically stops recording when the battery is out of power. Your Video will be saved before the camera powers OFF.



PHOTO MODE

Photo

To capture a Photo, verify the camera is in Photo mode. If the Photo icon on your camera's LCD screen is not showing, press the Power/ Mode Button repeatedly until it appears.

To take a photo:

Press the Shutter/Select Button. The camera will emit the camera shutter sound.



BURST PHOTO MODE

Burst Photo

To capture a Burst Photo series, verify the camera is in Burst Photo mode. If the Burst Photo icon on your camera's LCD screen is not showing, press the Power/Mode Button repeatedly until it appears. In Burst Photo mode, your camera takes 3 photos in 1.5 seconds.



To capture a Time Lapse series, verify the Continuous Lapse is ON and camera is in Time Lapse mode. If the Time Lapse icon on your camera's LCD screen is not showing, press the Power/Mode Button repeatedly until it appears. In Time Lapse mode, your camera captures a series of photos at 2, 3, 5, 10, 20, 30 or 60 second intervals.

To take Time Lapse:

Press the Shutter/Select Button. The camera initiates countdown and emits the camera shutter sound each time a Photo is taken.

Enable/disable Wi-Fi

Press and hold the **Down/Wi-Fi Button** for three seconds to turn **OFF Wi-Fi**.

APPLICATION (SUPPORT ANDROID AND IOS)

1. How to install an APP

1.1 Search for "Ez iCam" in Google Play or scan the QR code  printed on the gift box to find the APP and install it according to the instruction.

1.2 Search for "Ez iCam" in APP Store or scan the QR code below.



iOS



Android

2. Android APP

2.1 Install Ez iCam APP (provided by dealer or via internet) on smartphone or the product.

2.2 Insert the Micro SD card and turn on the camera, then press the Wi-Fi button to enable it. Now you can see the Wi-Fi icon on the LCD.

2.3 Enable Wi-Fi on smartphone or the product and search for wireless AP signal SY5003_WIFI, then connect it to camera, until the system displays “Connected successfully”.

Note: The first time connecting to **CHDW5003**, you need to enter password “**1234567890**”.

2.4 Click the icon  in the App list of the Android phone or the product to open it. Now you can preview the image sent by the camera on the phone or the product and start some operating.

3. iOS APP

3.1 Install Ez iCam APP on iOS phone or the product.

3.2 Insert the Micro SD card and turn on the camera, then press the Wi-Fi button to enable it. Now you can see the Wi-Fi icon on the LCD.

3.3 Enable Wi-Fi on iOS phone or the product and search for wireless AP signal SY5003_WIFI, then connect it to camera, until the system displays “Connected successfully”.

Note: The first time connecting to **CHDW5003**, you need to enter password “**1234567890**”.

3.4 Click the icon  in the App list of the iOS phone or the product to open it.

Now you can preview the image sent by the camera on the phone or the product and start some operating. The operation interface on terminal is shown in the following figure.

WATERPROOF CASE

- ◆ Before sealing the waterproof case, keep the camera housing's rubber seal clean, a single hair or grain of sand can cause a leak. You can test by closing the case without inserting the camera. Submerge the case completely in water for about a minute. Remove the case from the water, dry off its exterior with a towel, and then open the case. If the interior is dry, the case is safe for use under water.
- ◆ After use in salt water you will need to rinse the outside of the housing with fresh water and then dry. This will prevent corrosion of the hinge pin and salt buildup in the seal, which can cause failure.
- ◆ To clean the seal, rinse in fresh water and shake dry (drying with a cloth may cause lint to compromise the seal). Re-install the seal into the grooves in the backdoor of the housing.

SECURITY INFORMATION

This device was designed and built in order to guarantee your safety. The safety mechanisms implemented in the product will protect you if you observe the following installation, operation and troubleshooting procedures:

Please carefully read and follow the following instructions before handling and installing your device,

Keep these instructions for further reference.

GENERAL

Don't shake, or it may lead to damage to the product.

Only use components and accessories (power supply...) recommended by the manufacturer,

The illustrations of the product may vary from actual product.

SAFETY

To prevent fire or electric shock, do not put the appliance near objects filled with liquids;

If a heavy object or liquid is dropped on the device, unplug it immediately and send it to check by qualified personnel before re-use;

When in operation, the housing surface generates heat; do place the product on a flat and rigid surface and avoid covering it or placing any object on it.

PRODUCT'S POWER SUPPLY

In case you don't use the product for a long time or during a lightning storm, unplug the unit from the outlet by grabbing the plug itself, without pulling the cable.

The included power adapter is specific to the product. Using a different adapter may cause damage or accidents.

PLACING OF THE PRODUCT

Install the appliance away from any equipment with strong attraction such as microwave ovens, big speakers...

Place your product in a well-ventilated area and on a hard and flat surface to disperse heat from the device.

CLEANING

Never open the product to clean, otherwise the warranty will be canceled ;

Unplug the product from the wall outlet before cleaning the product ;

Clean the outside of the product using a soft, dry cloth. Never use an abrasive pad, scouring powder or solvent such as alcohol or gasoline.

TROUBLESHOOTING

Refer all troubleshooting to qualified personnel. Troubleshooting is required when the appliance has been damaged in any way: plug or cord is damaged, liquid spilled into the product, introduction of small objects in the product, exposure to rain or moisture, malfunction, drop of the product...

IMPORTANT NOTE

At full volume, for an extended period of time can damage your hearing. It is illegal to download music from the Internet without having bought the rights. STOREX is not responsible for the use of the STOREX product with illegal music downloading.

SAFETY-ENVIRONMENT

Your STOREX product has been laboratory tested; it complies with European guidelines corresponding to the CE labelling in force at the time of its launch.

Your STOREX product's components are traceable; this demonstrates the product's compliance to environmental guidelines (RoHS) in force at the time of its launch.

Once the product has reached the end of its lifespan, don't throw it in a dustbin. Return it to the retailer or bring it to a rubbish heap, to ensure the product is properly disposed of via a waste electrical and electronic equipment (DEEE) channel.

GUARANTEE CONDITIONS

STOREX's available guarantee is valid for 1 year for the product and 3 months for its accessories (remote control, AV cables, power supply ...).

STOREX guarantees your products against any manufacturing or assembling faults. This guarantee only applies to the first purchase of the product by the end user and is not transferable if the device is resold. This warranty does not cover any incompatibilities found by end user apart from recommendations specified on the packaging, or any other incompatibility generated by other hardware or software on the computer that is connected to the product.

Proof of purchase must be presented to our services to apply **STOREX** guarantee.

The guarantee doesn't cover failures or defects induced by non-compliance to this manual's instructions, neglect, alteration, improper installation or maintenance, reparation or alteration not authorized by **STOREX**, improper tests, accident or external factor such as (not exhaustive) excessive heat or dampness, power failures or bad installation / uninstalling of the product.

The only contractual obligation endorsed by **STOREX** pertains to the reparation or replacement of a defective product. In no case, **STOREX** cannot be held responsible for any loss of data, or its consequences induced by operational fault or a product failure.

In any case, **STOREX** won't be bound to any financial responsibility for any amount exceeding the value of the product purchased by the end user.

This guarantee is well defined and cannot be modified, decreased or increased without written consent from **STOREX**. In addition, **STOREX** cannot be held responsible for any technical advice or service provided in relation to the product.

For any request not covered by this guarantee, please contact **STOREX** support

STOREX WEBSITE

Go to <http://www.storex.eu>.

WARRANTY REGISTRATION

In order to facilitate the management of your issue, should you contact our support team, we invite you to register your product guarantee on our website at the following address:

<http://garantie.storex.eu>

For repairing, contact your dealer to repair your product under guarantee, or send your request via email to the following address:

support@storex.eu

or by phone at:

France: 01 55 85 82 00 (local call charge to Paris)

Spain: 902 110 572 (soporte.es@storex.eu)

Portugal: 308 800 836 (apoio.pt@support.eu)

England: (support.uk@storex.eu)

Monday to Thursday from 9:30 to 19:30.

Friday from 9:30 to 18:30.



STOREX